

vtech[®]

Instruction Manual

Dribble & Bounce Tiger



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech *Baby*

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® Dribble & Bounce Tiger!** Be on the winning team with the **Dribble & Bounce Tiger!** Get warmed up as Captain Tiger shows off impressive skills by dribbling and spinning the basketball. Then, try and catch Captain Tiger while moving around obstacles, getting little ones up and going. What a slam dunk!



Four Star
Buttons



On/Off/Mode
Switch

INCLUDED IN THE PACKAGE

- Dribble & Bounce Tiger
- Quick Start Guide


WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

Removing the Packaging Locks:



- ① Rotate the packaging locks 90 degrees anticlockwise.
- ② Pull out the packaging locks and discard.


INSTRUCTIONS

WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned **Off**.
2. Locate the battery cover located on the bottom of the unit, use a screwdriver to loosen the screw, and then open the battery cover.



3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 4 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product




The crossed-out wheeled bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

 Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:

www.vtech.co.uk/recycle

www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

PRODUCT FEATURES

1. On/Off/Mode Switch

To turn the unit **On**, slide the **On/Off/Mode Switch** to the **Learn Mode** (🎮) or the **Game Mode** (🐱) position. You will hear a song, phrases and sounds. To turn the unit **Off**, slide the **On/Off/Mode Switch** to the **Off** (OFF) position.



2. Automatic Shut-Off

To preserve battery life, the **Dribble & Bounce Tiger** will automatically power down after approximately 35 seconds without input. The unit can be turned **On** again by pressing a **Star Button** or by sliding the **On/Off/Mode Switch** to the **Learn Mode** or the **Game Mode** position.

NOTE

This product is in Try-Me mode. After opening the package, please turn **Dribble & Bounce Tiger Off** and **On** again to proceed with normal play.

If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Star Buttons

Press the four **Star Buttons** to hear numbers, songs, phrases, melodies and sound effects. If Captain Tiger is on the floor, he will spin or bounce the basketball and move with fun phrases and sounds. The light will flash with the sounds.



2. Front and Back Sensors

Captain Tiger is equipped with special sensors on the front and back of his shoes. Get close to the sensors to activate them and see Captain Tiger move while spinning or bouncing the basketball. Captain Tiger will respond with playful phrases, music and sounds. The light will flash with the sounds.



NOTE

The infrared light sensors in the shoes are sensitive to sunlight. The sensors may not perform properly in brightly lit, sunny rooms or under direct sunlight.

3. Pick-Up Sensor

Captain Tiger has a special sensor on the bottom of one of the wheels and knows when he has been picked up. Each time you pick him up, him will respond with a cute phrase and stop moving. The light will flash with the sounds.



MELODIES

1. It's Game Time! *by VTech®*
2. Dribble 'n Shoot *by VTech®*
3. Bring Home the Ball *by VTech®*
4. Here We Go Round the Mulberry Bush
5. London Bridge is Falling Down
6. Oh Where, Oh Where Has My Little Dog Gone?
7. One, Two, Buckle My Shoe
8. Bingo
9. Glow Worm
10. The Green Grass Grew All Around

SONG LYRICS

Song 1

Wig-wig-wig-wiggle, drib-drib-drib-dribble,
Who can make it possible? It's you!
Pick and roll, give and go,
Bounce, bounce, bounce, like a superhero!
Back to the court, play, play, play!
We win the game, hip-hip hoo-ray!

Song 2

The basketball goes up and down,
up and down, up and down.
Nothing but net like swish, swash, swoosh,
swish, swash, swoosh, oh yeah!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. For best performance, we recommend that you use new batteries. Otherwise the unit may move slowly.
6. We recommend that you avoid playing with the unit in bright sunlight or outdoors. Bright light will negatively affect the sensors.
7. We recommend that you play with this unit in open spaces that are free of obstacles to prevent the toy from running into objects.
8. For the best performance, we do not recommend playing with the unit on thick carpet or rugs. Solid, smooth surfaces are best.

9. If you receive an abnormal response or no response at all from the unit, please turn the unit **Off**, replace the batteries and then turn the unit **On** again.
10. We recommend always playing with this toy on clean surfaces. Dirt on the wheels could cause damage to the unit.
11. If the unit starts moving slowly, this is a sign that the batteries are low on power. We recommend replacing the batteries with an entire set of new batteries.
12. Do not roll the unit on your child's clothing, body or hair while the toy is turned on. If something gets caught in the wheels while the unit is turned **On**, slide the **Mode Switch** to the **Off** position.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

