

Parent's Guide

Twist & Explore Caterpillar



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

Pre-School

Interactive toys to develop their imagination and encourage language development

l want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

Birth-36 months

vtech Bally

stimulate their interest

in different textures, sounds and colours

...responding to colours,

sounds and textures

...understanding cause

...learning to touch, reach,

grasp, sit-up, crawl and

Tovs that will

lam...

and effect


toddle





INTRODUCTION

Thank you for purchasing the **Twist & Explore Caterpillar!**Discover sounds and movement with this lovable musical caterpillar!
This twistable caterpillar has sensory features for little hands and mouths to explore, including a light up heart that plays music.



INCLUDED IN THIS PACKAGE

- Twist & Explore Caterpillar
- · Parent's Guide

WARNING

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please keep this Parent's Guide as it contains important information.

Unlock the Packaging Locks:



- ① Rotate the packaging locks anticlockwise 90 degrees.
- 2 Pull out the packaging locks and discard.

GETTING STARTED

Battery Removal and Installation

- 1. Make sure the unit is turned Off.
- Find the battery cover on the back of the caterpillar's head. Use a screwdriver to loosen the screws and then open the battery cover.
- 3. Remove old batteries by pulling up on each side of the button cell battery.
- 4. Install 3 new LR44 batteries following the diagram inside the battery box.
- Replace the battery cover and tighten the screws to secure.



△ WARNING:

This product contains a button or coin cell battery. If swallowed, a button or coin cell battery can cause internal chemical burns in as little as two hours and can lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention and go straight to the nearest hospital emergency department.

Australia/New Zealand:

If you suspect your child has swallowed or placed a button cell/coin battery inside any part of their body, immediately call the 24-hour Poisons Information Centre on 13 11 26 (in Australia) or 24-hour National Poisons Centre on 0800 764 766 (in New Zealand) for fast, expert advice and go straight to the nearest hospital emergency room

BATTERY NOTICE

- Use three LR44 alkaline button cell batteries only for this toy.
- The button cell batteries used with this product should be kept away from small children who might still put things in their mouths. If the button cell batteries are swallowed, consult a doctor immediately.
- Insert the button cell batteries with the correct polarity (+ and -).
- · Do not use damaged button cell batteries.
- · Do not short-circuit the button cell battery terminals.
- Remove exhausted button cell batteries from the product.
- Remove button cell batteries during long periods of non-use.
- · Do not dispose of button cell batteries in fire.
- Do not charge non-rechargeable button cell batteries.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit: www.recvcle-more.co.uk

www.recyclenow.com

PRODUCT FEATURES

1. On/Off Switch

To turn the unit **On**, slide the **On/Off Switch** to the **On** ★ position. You will hear a song, a cute phrase and a sound. To turn the unit **Off**, slide the **On/Off Switch** to the **Off** ◆ position.



2. Automatic Shut-Off

To preserve battery life, the **Twist & Explore Caterpillar** will automatically shut off after approximately 25 seconds without input. The unit can be turned on again by pressing the **Heart Button**.

NOTE: If the unit powers down or if the light fades out during play, please install a new set of button cell batteries.

ACTIVITIES

1. Heart Button

Press the **Heart Button** to hear fun phrases, songs, melodies and sounds. The light will flash with the sounds.



2. Twisting Segments

Twist, turn, shake and spin the caterpillar to help develop important motor skills.



MELODY LIST

- 1. Daring Young Man on the Flying Trapeze
- 2. Three Little Kittens
- 3. Humpty Dumpty
- 4 Alouette
- 5. Yankee Doodle
- 6. Ring Around the Rosy
- 7. Aiken Drum
- 8. Hey Diddle Diddle
- 9. Jack Be Nimble
- 10. A-Tisket A-Tasket
- 11. Diddle, Diddle Dumpling
- 12. Teddy Bear's Picnic

SONG LYRICS

Song 1

I twist and I turn, I bend and I spin.

I like to move and wiggle, wiggle, wiggle!

Song 2

I'm a busy caterpillar,

I live in the grass and nibble on leaves.

CARE & MAINTENANCE


- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Remove the batteries when the unit will not be in use for an extended period of time.
- Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **ON**. The unit should now be ready to play again.
- 5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.



CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk www.vtech.com.au

