

vtech®

Parent's Guide

**Toot-Toot  
Friends™**

## **My Magical Unicorn**



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

### vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

#### I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



### Pre-School

Interactive toys to develop their imagination and encourage language development

#### I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



### Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

#### I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

## INTRODUCTION

Thank you for purchasing the **VTech® Toot-Toot Friends™ My Magical Unicorn!** Place Fairy Luna on the **MagicPoint™** location to hear fun sounds and responses! Press Unicorn Twinkle's heart button to see her walk, move her head, flap her wings, watch her horn light up in different colours and more! Interact with Twinkle using the Magic Wand and see her come to life with motion, lights and even more fun responses!



## INCLUDED IN THIS PACKAGE

**NOTE:** This toy is not intended for teething.



One **Magical Unicorn - Twinkle**



One **MagicPoint™** Character - Fairy Luna



One Mini Unicorn



One Magic Wand


• One Parent's Guide

### **WARNING:**


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

**NOTE:** Please keep this Parent's Guide as it contains important information.

### **Removing the Packaging Locks:**



- ① Rotate the packaging lock anticlockwise for 90 degrees.
- ② Pull out the packaging lock.




- ① Rotate the packaging lock 90 degrees anticlockwise.
- ② Pull out the packaging lock and discard.

## GETTING STARTED

### Battery Removal and Installation

1. Make sure that the unicorn is turned **Off**.
2. Locate the battery cover on the bottom of the unicorn. Use a screwdriver to loosen the screw and remove the cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 4 new AA (LR6/AM-3) batteries following the diagram inside the battery box. For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.
5. Replace the battery cover and tighten the screw to secure.



**WARNING:** Adult assembly required for battery installation. Keep batteries out of reach of children.

### IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

## RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

## Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit [www.recyclenow.com](http://www.recyclenow.com) to see a list of collection points near you.

In Australia & New Zealand:

Check with your local council for kerbside collections.

## NOTE


This product is in Try-Me mode in the packaging. To activate Normal Play mode, please follow these steps.

1. Turn the unit **On**.
2. Place Fairy Luna on the **MagicPoint™** location.
3. When you hear two short sounds, normal game play has been activated.

# PRODUCT FEATURES

## 1. Off/Low/High Volume Switch

To turn the unit On, slide the switch to either the **Low Volume** (🔊) or **High Volume** (🔊) position. To turn the unit Off, slide the switch to the **Off** (🔇) position.



## 2. Heart Button

Press the **Heart Button** to hear Twinkle sing, talk, move her head, walk and flap her wings. Listen and interact with Twinkle to enjoy fun and imaginative role-play situations with motion, lights and more!



## 3. MagicPoint™ Location

There is one **MagicPoint™** located on the unit. Place the **MagicPoint™** character onto the **MagicPoint™** location to hear fun responses. The **MagicPoint™** location can also interact with other **VTech® Toot-Toot Friends™** characters (each sold separately).



## 4. Sound Sensor

There is one **Sound Sensor** installed in the unit. The **Sound Sensor** can receive sounds. Follow Twinkle's instructions by casting magic spells, clapping your hands, and waving the magic wand to enjoy fun situations.

## 5. Magic Wand

Listen to Twinkle and wave the **Magic Wand** when she says to trigger fun sounds with motion, music and lights.

## 6. Automatic Shut Off

To preserve battery life, the **VTech® Toot-Toot Friends™ My Magical Unicorn** will automatically power down after several minutes of no input. The unit can be turned on again by sliding the **Off/Low/High Volume Switch** to the **Low Volume** or **High Volume** position, or by pressing the **Heart Button**.

## NOTE

If the unit powers down while playing, we suggest installing a brand new set of batteries.

## ACTIVITIES

Slide the **Off/Low/High Volume Switch** to either the **Low Volume** or **High Volume** position to turn the unit on.

1. Press the **Heart Button** to hear Twinkle sing, talk, shake her head, walk and flap her wings. Her horn will also light up in multiple colours.



2. Place Fairy Luna onto the **MagicPoint™** location to her sing and talk.





3. Sometimes, Twinkle will ask for your help. You can interact by pressing the **Heart Button**, placing Fairy Luna onto the **Magic Point™** location, clapping your hands, casting a magic spell or waving the **Magic Wand**.



## SONG LYRICS

Song 1. Fairy Luna & Unicorn Twinkle  
Magic, Adventure, Exploring, Together!

We can have so much fun, when we use our imagination!

Song 2. Fairy Luna

I'm Luna the little Fairy,

I love to ride with Twinkle.

Would you like to play with us, and explore our magical world?!

Song 3. Fairy Luna & Unicorn Twinkle

You're the best friend that I've ever had. (Unicorn)

We'll be best friends forever and ever. (Fairy)

Life's better, when we adventure together! (Unicorn & Fairy)

Song 4. Fairy Luna & Unicorn Twinkle

Riding in the breeze, flying through the sky,

Exploring the forest, just you and I,

Having a magical day, singing hip hip hooray!

Song 5. Unicorn Twinkle

If you're magic and you feel it, wave your wand!

If you're magic and you feel it, wave your wand!

If you're magic and you feel it, and you really do believe it!

If you're magic and you feel it, wave your wand!

## CARE & MAINTENANCE

1. Keep the product and its metal parts clean by wiping them with a slightly damp cloth.
2. Keep the product out of direct sunlight and away from any direct heat sources.
3. Remove the batteries when the product is not in use for an extended period of time.
4. Do not drop the product on a hard surface and do not expose the product to excess moisture or water.

## TROUBLESHOOTING

If for some reason the toy stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.

If the toy still does not function, or if for some reason the toy stops working or malfunctions on its own, please follow these steps:

2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

If the problem persists, please contact our Consumer Services.

Department and a service representative will be happy to help you.

## CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

### **UK Customers:**

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)  
Website: [www.vtech.co.uk/support](http://www.vtech.co.uk/support)

### **Australian Customers:**

Phone: 1800 862 155  
Website: [support.vtech.com.au](http://support.vtech.com.au)

### **NZ Customers:**

Phone: 0800 400 785  
Website: [support.vtech.com.au](http://support.vtech.com.au)

## PRODUCT WARRANTY/ CONSUMER GUARANTEES

### **UK Customers:**

Read our complete warranty policy online at [vtech.co.uk/warranty](http://vtech.co.uk/warranty).

### **Australian Customers:**

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to [vtech.com.au/consumerguarantees](http://vtech.com.au/consumerguarantees) for further information.



**Visit our website for more  
information about our products,  
downloads, resources and more.**

***[www.vtech.co.uk](http://www.vtech.co.uk)***  
***[www.vtech.com.au](http://www.vtech.com.au)***



TM & © 2021 Vtech Holdings Limited.  
All rights reserved.  
Printed in China.